Abmessungen Enya Düsenstöcke, Durchmesser 4mm



Referenz	verwendet in ENYA	A	В
09220	.09	5,5 mm	14 mm
15220	.111519	6,5 mm	15 mm
29420	.1925303540XZ	7,0 mm	16 mm
60220	.405061	9,0 mm	18 mm
S5020	.4061	9,0 mm	12 mm

S5020 NEELDE VALVE ASSEMBLY



ENYA C/L ENGINE suitable for S5020 >>> SS40, SS45, SS50, 45CX, 50CX, 61CX, 60-IIIB

Directions for use

- 1. Point that needs to be checked first
- a) Loosen the spray bar holder ④. However it must not be removed from the spray bar ②.
- b) Close the needle ① clockwise, and confirm whether the needle completely closes.
 (The needle closes about 18 times.)
- Installation to the engine Insert the spray bar ② into the engine, and fix it by the lock nut ⑤.
- Adjustment of the needle
- a) Close the spray bar holder ①, and confirm whether the needle ① completely fixes.
- Regulate the hardness of the needle rotation with your liking, while you loosen the spray bar holder @ gradually.
- c) Start your engine, and adjust the needle valve to suitable position.

Attention for handling

- 1. The needle ① closes about 18 times. Don't tighten further it by force.
- The needle ① may be hard to enter in the inner part because the buffer tube ③ is obstinate at first. It will fit in with the needle ①, while that closes and opens several times.
- When you remove the needle ① and spray bar holder ④ at the same time, the needle holder
 easily falls out; therefore you must be careful not to lose it.

EXPLODED VIEW



① Needle / ② Spray bar / ③ Buffer tube / ④ Spray bar holder / ⑤ Needle holder ⑥ Lock nut / ⑦ Spacer washer set (optional parts)

Supplementary explanation

- 1. Reference data of the needle valve for 50 \sim 61 class engine \cdot \cdot 3 \sim 4 times.
- 2. Replace with the new buffer tube ③ if the effect as rubber fades away by the passage of time.
- 3. Use the spanner of flat diameter 6 and 6.5. There is the following tool of the release from us.
 - · ETS13 Spanner (5.5×6) ¥420 · ETS14 Spanner (6.5×7) ¥420
- 4. If you use this product for a small engine (11CX, SS15 \sim SS35, 35X etc.), please try the following part. The hole position of the spray bar can be moved to the axial center .
 - · SPW4S Spacer washer set (3 pcs) ¥105

ENYA METAL PRODUCTS CO., LTD.

16-3 TIKUMASAWA-HIGASHI IRUMA-GUN MIYOSHI-CHO SAITAMA 354-0046 JAPAN