

# Sonos

# Tone Table

TONE	TONE TYPE	TONE DESCRIPTION/ APPLICATION	2 <sup>ND</sup> STAGE TONE	DIP SWITCH 1_2_3_4_5	SOUND LEVEL (dBA @ 1m)	AVERAGE CURRENT (mA)
1		970Hz (BS5839-1:2002)	4	0-0-0-0-0	97	18
2		800Hz/970Hz @ 2Hz (BS5839-1:2002)	1	0-0-0-0-I	97	17
3		800Hz - 970Hz @ 1Hz (BS5839-1:2002)	1	0-0-0-I-0	98	17
4		970Hz 1s OFF/1s ON (Apollo Fire Systems Alert Tone, BS5839-1:2002)	1	0-0-0-I-I	96	11
5		970Hz, 0.5s/ 630Hz, 0.5s (Apollo Fire Systems Alert Tone, BS5839-1:2002)	4	0-0-I-0-0	97	16
6		554Hz, 0.1s/ 440Hz, 0.4s (France - AFNOR NF S 32 001 )	1	0-0-I-0-I	96	10
7		500 - 1200Hz, 3.5s/ 0.5s OFF (Netherlands - NEN 2575:2000)	1	0-0-I-I-0	99	13
8		420Hz 0.625s ON/0.625s OFF (Australia AS2220 Alert tone)	9	0-0-I-I-I	93	8
9		500 - 1200Hz, 3.75s/ 0.25s OFF (Australia AS2220 Evacuation tone)	8	0-I-0-0-0	99	13
10		550Hz/440Hz @ 0.5Hz	1	0-I-0-0-I	99	11
11		970Hz, 0.5s ON/0.5s OFF x 3/ 1.5s OFF (ISO 8201 Low tone)	12	0-I-0-I-0	97	9
12		2850Hz, 0.5s ON/0.5s OFF x 3/1.5s OFF (ISO 8201 High tone)	11	0-I-0-I-I	93	20
13		1200Hz - 500Hz @ 1Hz (DIN 33 404)	1	0-I-I-0-0	97	14
14		400Hz	6	0-I-I-0-I	92	10
15		550Hz, 0.7s/1000Hz, 0.33s ('SafeSound')	1	0-I-I-I-0	99	14
16		1500Hz - 2700Hz @ 3Hz (Vandal Alarm)	1	0-I-I-I-I	105	32
17		750Hz	27	I-0-0-0-0	98	15
18		2400Hz	26	I-0-0-0-I	106	35
19		750Hz 0.33s ON/0.51s OFF	1	I-0-0-I-0	98	8
20		750Hz 0.51s ON/0.33s OFF	1	I-0-0-I-I	98	10
21		800Hz 0.2s ON/0.2s OFF	1	I-0-I-0-0	97	9
22		510Hz, 0.5s/ 610Hz, 0.5s	4	I-0-I-0-I	95	12
23		550Hz, 0.33s/1000Hz, 0.7s	1	I-0-I-I-0	99	17
24		250Hz - 1200Hz @ 12Hz	18	I-0-I-I-I	94	10
25		500Hz - 1200Hz @ 0.33Hz.	18	I-I-0-0-0	99	14
26		2500Hz - 2850Hz @ 7Hz.	18	I-I-0-0-I	98	45
27		600Hz - 900Hz/ 0.9s	1	I-I-0-I-0	97	15
28		660Hz - 680Hz/ 0.9s	1	I-I-0-I-I	95	14
29		670Hz - 725Hz/ 0.9s	1	I-I-I-0-0	96	15
30		920Hz - 750Hz/ 0.9s	1	I-I-I-0-I	98	16
31		700Hz - 900Hz, 0.3s/0.6s OFF	1	I-I-I-I-0	97	7
32		900Hz - 760Hz, 0.6s/0.3s OFF	1	I-I-I-I-I	98	11